

200- Completed after trenches or ditches are excavated, piping installed and before backfill is put in place. All piping required to be tested per FBC Building Section 110, FBC Plumbing Section 312 and FBC Residential Section P2503

