

403- To be made after trenches or ditches are excavated, piping installed, and before back fill is put in place. Warning/Locating tape should be installed and a pressure test should be performed.

